

# Storage with Style Basket Systems

Installation Instructions for the SWS-WB Series

Scan to watch the installation video https://delivr.com/2eyqn



# **IMPORTANT:**

Before you begin, make sure you familiarize yourself with all the parts and fully read the instructions.

# **CUSTOMER SERVICE:**

Toll free customer help line available weekdays between 7:00am and 6:00pm Central Time at 800-463-0660.

# **TOOLS NECESSARY:**

Screw gun or Phillips screwdriver and tape measure. NOTE: If screw gun has a clutch, set to lowest setting so as not to over tighten and/or strip screws.


# STEP 1



Remove the bottom insert panel. Remove the basket from the slides by pressing inward on the slide release clip.

### STEP 2

SIDE MOUNT INSTALLATION




Loosen the Extension Arm Screws (D).

### STEP 3




Measure 1-3/8" from behind face frame to the Slide Assembly (C).

# **PARTS IDENTIFICATION:**




Α	Basket Organizer	1 pcs
В	Bottom Panel Liner	1 pcs
С	Slide Assembly	1 pcs
D	Extension Arm Screws	4 pcs
Е	Slide Mounting Screws	8 pcs
F	Extension Arm	4 pcs

### STEP 4



Use 8 - #8 x 3/8"flat head screws (not included) to affix Extension Arms (F) to the side of the cabinet.

### STEP 5



Tighten Extension Arms Screws (D) at desired location.

### STEP 6



Reattach Basket Organizer (A) to Slide Assembly (C) by pushing back until audible click.


# **BOTTOM MOUNT INSTALLATION**

# STEP 1



Remove the bottom insert panel. Remove the basket from the slides by pressing inward on the slide release clip.

# STEP 2



Remove the Extension Arm Screws (D) and loosen the Slide Mounting Screws (E) from slides.

### STEP 3




Remove 4 - Extension Arms (F) from Slide Assembly

# STEP 4


Tighten Slide Screws back up.

# STEP 5



Measure 1-3/8" from behind face frame to the Slide Assembly (C).

# STEP 6



Attach to bottom of cabinet using #8 x 1" flat head screws. (Included)

# STEP 7



Reattach Basket Organizer (A) to Slide Assembly (C) by pushing back until audible click.